

# Real Rain Screen Siding Installation Instructions

Before installing siding, windows must be trimmed. Corners can be overlay trimmed after siding installation. Order lumber without the siding profile to use for trim.

1. Mark line where bottom of siding should be;
2. Fasten  $\frac{3}{4}$ " thick furring strips vertically to wall over studs;
3. Fasten first line of Real Rain Screen Siding clips to furring strips where you want bottom of first siding board and set board onto clips;
4. Set clips onto top of first board, fasten to furring strips;
5. Set next board in place on top of clips;
6. Repeat last 2 steps.



Call us for additional technical assistance.  
Brazilian Wood Depot 770-242-0045